


SilTite™

The New Metal Ferrule for
Fused Silica Capillary Columns



1. Unscrew the insulation cup fitted around the column nut inside the oven.
2. Remove the column nut(e) and reducing nut(c) from the injector.
3. Remove the base seal from the reducing nut and place the gold SilTite base seal(a) in its place (cross-side up) re-using the original washer(b).
4. Install the column(f) (as above) and tighten the nut until the SilTite ferrule(d) grabs, then tighten a further 60° for a leak Tite seal.

